



VELO

Models

899 YM A69 VP

898 YM A69 VP

897 YM A69 VP

- A Seat Height Adjustable**
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.
- B Multi-Position Tilt Lock**
Recline to desired position, and turn lever anti-clockwise to lock. Turn lever clockwise to release tilt-lock.
- C Armrest Height**
Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.
- D Seat Depth Adjustment**
Pull the lever under the right-side of the seat to adjust fore and aft position.
- E Armpad Angle**
Grasp armpads and rotate them inwards or outwards to adjust elbow support to suite specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.
- F Armrest Depth**
Grasp armpads and push them forwards and backwards to suite your arm support.

