
## Assembly Instruction





## Fulkrum models: P079 YF B6S V

odels: P079 YF B6S V P069 YF B6S V P068 YF B6S V P067 YF B6S V

