





USER **INSTRUCTIONS**

Seat Height Adjustable
Flip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.

Multi-Position Tilt Lock Recline to desired position, and flip up lever on left-side to lock. Flip down lever to release tilt-lock.

Tilt Tension Control Turn bottom lever clockwise to provide a stronger tilt tension, and vice-versa. Adjust such that minimum effort is required to push back when reclining.

