





USER INSTRUCTIONS

Seat Height AdjustableFlip up lever on right-side to raise or lower seat. Adjust such that your feet are adequately supported on floor.

Tilt Tension Control B

Turn bottom knob clockwise to provide a stronger tilt tension, and vice-versa. Adjust such that minimum effort is required to push back when reclining.

