
Assembly Instruction



User Instructions

FORTE

Models 961 NA A69 B

Armrest Height

Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.

B Armrest Width

Turn bottom knob clockwise to loosen the armrest and adjust inwards or outwards to suite your shoulder width.

C Armpad Angle

Grasp armpads and rotate them inwards or outwards to adjust elbow support to suite specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.

Armrest Depth

Grasp armpads and push them forwards and backwards to suite your arm support. $% \label{eq:controlled}$

Lumbar Height Adjustment

Slide the lumbar support up or down for desired lumbar position.

