









Assembly Instruction

MERRYFAIR®



Silver Surf

model: MSC471 BACK

