



Assembly Instruction

MERRYFAIR®



Esie
model: 361 NA A4S B



User Instructions

MERRYFAIR®

A *Armrest Height*

Press the button and raise or lower the armrest. Adjust height to adequately support elbows to take strain off shoulders.

B *Armrest Width*

Turn bottom knob clockwise loosen the armrest and adjust inwards or outwards to suite your shoulder width.

C *Armpad Angle*

Grasp armpads and rotate them inwards or outwards to adjust elbow support to suit specific tasks. An inward position works during keyboard use, while an outward position is recommended during mousing.

D *Armpad Depth*

Grasp armpads and push them forwards or backwards to suite your arm support.

Esie

model: 361 NA A4S B

